

One Touch Static Dissipating Ground Pad

Instructions for Use: This device must be grounded. To do so simply slip the ring terminal from the ground cord over the third prong of an AC power plug and plug it back in (figure 2). OR attach the ring terminal to the center screw of an AC electrical face plate cover (figure 1). Remove the wax paper liner from the bottom of the pad and place it on (or close to) the device you wish to protect.

Simply touch the pad before you touch your static sensitive electronics. Yes, it's THAT simple.

Telephone: 719 676 3928

Ground Methods:



Figure 1



Figure 2